

- 1x 6031962
- 3x 6346517
- 2x 6321305
- 1x 6317653 (4)
- 17x 6083620
- 2x 4525184
- 2x 6331431 (21)
- 2x 6271589
- 2x 4499858 (8)
- 7x 4645730 (9)
- 2x 4603472 (11)
- 2x 6207990


- 2x 614101
- 1x 4544140
- 2x 6343987 (22)
- 2x 6330084 (21)
- 5x 6179606
- 2x 6265135
- 2x 6212049
- 7x 6375684
- 1x 6276052
- 4x 6268001 (7)
- 5x 4495927 (9)
- 2x 6001831
- 7x 4565452
- 1x 4666579

- 7x 6271820
- 5x 6323573
- 3x 6360104
- 17x 6332580
- 1x 6173126
- 15x 4142865
- 1x 6313493
- 1x 6100930
- 6x 6364451
- 6x 6273712
- 20x 6209519
- 2x 6347789
- 2x 6351572
- 2x 6330205 (6)
- 1x 6130002


- 5x 6274738
- 2x 6251294
- 23x 4143005
- 27x 4206482
- 1x 6224999
- 54x 6299413
- 2x 6271167
- 2x 4112203
- 2x 4119474 (5)
- 10x 6130008
- 6x 6282140
- 15x 6121485
- 21x 6044702
- 4x 4177431
- 2x 6338428
- 58x 6279875

- 6x 6179182
- 5x 6099801
- 21x 6265091
- 2x 6326047
- 2x 6349281
- 2x 6173119
- 4x 6271346
- 4x 6313520
- 3x 6331723
- 2x 6093525
- 2x 6284188
- 1x 6271810
- 2x 6273708
- 10x 6089119

- 20x 6036503
- 2x 6135494
- 9x 6321745
- 5x 4107765
- 2x 6261386
- 4x 4142822
- 4x 6362991
- 6x 6286381
- 12x 370526
- 2x 6326620
- 4x 6331570
- 8x 6271825
- 8x 6327028
- 6x 4299389



2x 6159763



1x 6179850



1x 6268012



5x 4495935



2x 6150082



6x 6325260



4x 6271152



2x 6330585



4x 6080356



4x 4210676



1x 6167281



8x 4552349



2x 6284582



2x 6352662




2x 6340604



11x 6143028



4x 6347790




2x 6339024



1x 6224785



4x 6271162



2x 6358259



2x 6251290



2x 4652235



4x 6282158



16x 6331441



5x 6271165



3x 6183784



1x 4211375



8x 6261375



5x 4211807



1x 4640536



1x 4521532



2x 6000018



2x 6279023



36x 4211815



12x 6276969



6x 6027565



2x 4234251



4x 4211713



4x 4211651



3x 4211805



3x 4539880



2x 6012451



1x 6100931



1x 6347464

Customer Service
Kundenservice
Service Consommateurs
Servicio Al Consumidor
LEGO.com/service or dial

: 00800 5346 5555
 : 1-800-422-5346